

# **To load a HQ Pro-Stitcher software update version 16.01.0092**

As updates for the Pro-Stitcher software become available, download the updated file from the Handi Quilter website, [www.HandiQuilter.com](http://www.HandiQuilter.com).

## **Begin by downloading the updated software from the Handi Quilter website.**

1. Insert a USB drive into the USB port of a computer connected to the Internet.
2. In a browser window, navigate to the Handi Quilter website: [www.handiquilter.com](http://www.handiquilter.com)
3. Select Downloads and then select HQ Pro-Stitcher Software Update.
4. Click the link to download the current version, such as 16.01.0092. Then select Download when the Dropbox download screen appears.
5. Save the zipped file to the Downloads folder on the computer.
6. Locate the folder with the zipped file, such as PSUpdate.16.01.0092\_H.zip. Right-click the folder name and select Extract All to unzip the update file.
7. Copy the unzipped executable file, such as PSUpdate.16.01.0092\_H.exe, from the folder to the USB drive.

## **To install the updated software**

1. Turn on the HQ Pro-Stitcher tablet and plug the USB flash drive into a USB port on the Pro-Stitcher computer. Wait for approximately 10 seconds while Pro-Stitcher accesses the USB flash drive and updates the software.
2. Alternately, choose Design and then File. Then navigate to the folder on the USB drive with the executable file, select the file, and then select the Update button.
3. If the Pro-Stitcher software closes in step 2, but the update does not start, you can start it manually by opening a file browser\*, locating the executable file, and right-clicking the file name and selecting Run as administrator.

\*To open a file browser on a Pro-Stitcher tablet, press the gray bar at the top left corner of the screen to open a keyboard. After the keyboard appears, press the Windows key followed by the letter e.